

Time Mode (default view)

A or C Key: Turn on backlight
B (Mode) Key



Compass Mode:

Hold A Key: Save current heading
Hold C Key: Set compass declination
B (Mode) Key



Dive Set Mode:

A Key: Selects value to be set, scrolls through values as follows:
Dive/Gage → Mix1 PO₂ → Mix1 FO₂ → Mix2 PO₂ → Mix2 FO₂ → Mix3 PO₂ →
Mix3 FO₂ → Depth Alarm → Depth Alarm On/Off → Dive Time Alarm → Dive
Time Alarm On/Off →
Deep Stops On/Off → Fresh/Salt water → Profile Interval → User Safety Factor
C Key → Changes selected value
B (Mode) Key



Plan Mode:

A Key: Decrease plan depth
C Key: Increase plan depth
Hold B (Mode) Key → Time Mode
B (Mode) Key



Dive Log Mode:

A Key → Next page in log (3 pages per dive)
C Key → Previous page in log
B (Mode) Key



Dive Profile Mode:

A Key → Next dive in log
C Key → Previous dive in log
B (Mode) Key



History Mode:

B (Mode) Key



PC Transfer Mode:

B (Mode) Key



Time Set Mode:

A Key: Selects value to be set, scrolls through values as follows:
Seconds → Minute → Hour → Year → Month → Day → 12/24 Hour display
C Key → Changes selected value

Water Detected

All keys Lock
Depth exceeds 4 ft



Dive Mode:

Any key will activate backlight.
A Key → Demand Screen A → Demand Screen B
Hold B (Mode) Key → Mix Change



A Key → Select Mix

C Key → Compass Mode



Hold A Key → Save current orientation
B (Mode) Key → Toggle display between Dive Time and Depth
C Key → return to Dive Mode

Hold C Key → Saves bookmark in Dive Profile
Depth less than 4 ft



All keys Lock
No water detected



Surface Mode

Please refer to your N2iTion3 Owner's Manual for full explanation of all features, as well as initial setup instructions and important warnings.

Notes:

Fold Here